





DVD PLAYER





AC/DC ADAPTER  
*(not included)*

**TV CONNECTIONS**




**DVD CONNECTIONS**




**CONVERTER BOX** *(back)*

**CONVERTER BOX** *(front)*

**EXTRA MICROPHONE**  
*(not included)*




**MICROPHONE**  
*(included)*





LECTEUR DVD




ADAPTATEUR C.A./C.C.  
(pas inclus)

CONNEXIONS TV




CONNEXIONS DVD



CONVERTISSEUR (arrière)

CONVERTISSEUR (avant)

MICROPHONE  
SUPPLÉMENTAIRE  
(pas inclus)



MICROPHONE  
(inclus)

